



1. Die-cut from desired material.



2. Fold all creases in the same direction



3. Adhere the corner tabs to the inside of the adjoining panels. Attach the center or back tabs to the section that will become the bottom of the box.

